



Lightly apply heat in this area

Lightly apply heat in this area

If truck is 1998 or older you may need to reuse original side channels.  
**NOTE:** Remove bolts and apply heat to soften adhesive between core and brackets to remove.